

**TO ARM SYSTEM:** System must say õKnight Security Ready to Armö. Enter 4-digit code and push õAwayö (Digit #2 if leaving). Enter 4-digit code and push õStayö (Digit #3 if staying in building).

**TO DISARM:** Enter 4-digit code and push õOffö (Digit #1).

**TO BYPASS:** Enter 4-digit code, 6 and then the zone number.

## If Accidental Alarm

Disarm system with instructions above. Then call Knight Security at (760) 745-3604 & give name and code to cancel police dispatch.