


# WASTE SEGREGATION • EPA DEFINED – FOR SMALL QUANTITY



CONTAINER					
WASTE CLASS	<b>HAZARDOUS Rx WASTE</b>	<b>INCOMPATIBLE Rx WASTE</b>	<b>MAINTENANCE IV SOLUTIONS</b>	<b>TRACE CHEMOTHERAPY WASTE</b>	<b>SHARPS/ INFECTIOUS WASTE</b>
DESCRIPTION AND EXAMPLES OF WASTE	<p>Approximately 99% of all Rx waste will be placed in this container.</p> <ul style="list-style-type: none"> <li>• Antibiotics</li> <li>• Tylenol</li> <li>• Aspirin</li> <li>• Lotions, creams or ointments (capped or in recloseable clear bag)</li> <li>• Tablets, capsules</li> <li>• Rx samples</li> </ul> <p><b>P-Listed Acutely Hazardous Waste (PBKC)</b> - examples:</p> <ul style="list-style-type: none"> <li>• Nicotine / Nicotrol</li> <li>• Coumadin / Warfarin</li> </ul> <p><i>Place full, partial and empty packaging/containers and excess medication into a 1.5 quart P-Listed container.</i></p> <p><b>Bulk Chemotherapy Waste</b></p> <ul style="list-style-type: none"> <li>• Vials, Syringes, Ampoules</li> <li>• IV bags and tubing</li> <li>• Saturated gloves, gowns &amp; wipes</li> </ul>	<p>Incompatible Rx wastes – including Aerosols, Corrosives, Oxidizers and Lab Pack must be packaged and shipped in separate hazardous waste containers per EPA and US DOT regulations.</p> <p><b>Aerosols/Flammable (SP)</b> - examples:</p> <ul style="list-style-type: none"> <li>• Albuterol</li> <li>• Hurricane Spray</li> <li>• Tinactin</li> </ul> <p><b>Corrosives (SPC)</b> - examples:</p> <ul style="list-style-type: none"> <li>• Pyridoxine HCL</li> <li>• Hydrochloric acid</li> </ul> <p><b>Oxidizers (SPO)</b> - examples:</p> <ul style="list-style-type: none"> <li>• Potassium Permanganate</li> <li>• Unused Silver Nitrate</li> </ul> <p><b>Lab Pack</b> - example:</p> <ul style="list-style-type: none"> <li>• Botox</li> </ul>	<p><b>IV solutions without Rx medication instilled that may be disposed of down the drain include:</b></p> <ul style="list-style-type: none"> <li>• Potassium chloride</li> <li>• Potassium phosphate</li> <li>• Sodium phosphate</li> <li>• Calcium</li> <li>• Sodium Bicarbonate</li> <li>• Dextrose</li> <li>• Saline</li> </ul>	<p>Chemotherapy containers that have <b>NO</b> observable content remaining in the container and, PPE that is not saturated, are considered "TRACE".</p> <ul style="list-style-type: none"> <li>• Empty Vial</li> <li>• Empty Syringe</li> <li>• Gown</li> <li>• Gloves</li> <li>• Goggles</li> <li>• Wipes</li> <li>• Empty IV / Tubing</li> </ul> <p><b>NOTE:</b> Any chemotherapy container that has observable content or saturated PPE is considered <b>BULK</b> – see Hazardous Rx Waste.</p>	<ul style="list-style-type: none"> <li>• Needles</li> <li>• Empty Syringes</li> <li>• Ampoules</li> <li>• Other infectious wastes that are not hazardous</li> </ul> <p style="text-align: center;"><b>EMPTY SHARPS PERMITTED</b></p>
NOT PERMITTED	<p><b>NO CONTROLLED SUBSTANCES</b></p> <p><b>NO BLOOD PRODUCTS OR INFECTIOUS WASTE</b></p> <p><b>NO FREE LIQUIDS</b></p>	<p><b>NO CONTROLLED SUBSTANCES</b></p> <p><b>NO BLOOD PRODUCTS OR INFECTIOUS WASTE</b></p> <p><b>NO FREE LIQUIDS</b></p>	<p><b>CONTROLLED SUBSTANCES — FOLLOW FACILITY'S APPROVED POLICY</b></p>	<p><b>NO CONTROLLED SUBSTANCES</b></p> <p><b>NO BULK CHEMO WASTE</b></p>	<p><b>NO CONTROLLED SUBSTANCES</b></p> <p><b>NO Rx MEDICATIONS</b></p>

*"Simply Compliant for Your Healthcare Facilities"*

